



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Hyper Intake : 908-113 / Dragon Intake : 808-113**

Application : **1994-03 Mercedes 6cyl**

Part #'s **Hyper Intake : 908-115 / Dragon Intake : 808-115**

Application : **1990-04 BMW 6cyl**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 3" Clamp
1 x 2.5-3" Coupler / 1 x Weapon*R Decal / 1 x Intake Bracket kit.**

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3" Coupler / 2 x 3" Clamps

- 1 Using tools remove stock air box and OEM Clamps, put aside for later use.
- 2 Place the 2.5"- 3" Coupler onto the front of the Air Flow Meter and clamp down with the OEM clamp.
- 3 Place a supplied Stainless Steel Clamp onto the 3" end of the 2.5"- 3" Reducer hose.
- 4 Place Weapon*R Intake Tube into the 3" end of Reducer hose and clamp down Stainless Steel Clamp.
- 5 Attach Weapon*R Filter to end of Weapon*R Intake Pipe, clamp down.
- 6 **Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
Install the 3" coupler onto intake pipe, secure with supplied clamp.
- 7 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
- 8 Install U-shaped part of intake system bracket under the clamp on air filter.
- 9 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 10 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 11 Secure with washer and nut included in bracket kit.
- 12 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 13 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 14 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note : Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

