



CARB PENDING

Recommended filter cleaning interval every 3000 miles

Part # 's **Hyper Intake : 908-116 / Dragon Intake : 808-116**

Application : **1999-03 Volkswagen JETTA / GOLF / 1.8T & 2.0L & VR6**

Parts List : **1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 3" Clamp/ 1" Hose 4 inch long
1 x 2.75-3" Coupler / 1 x Weapon*R Decal / 1 x Intake Bracket kit.**

Note: Additional Parts needed when you have a Dragon Filter, 2 x 3" Coupler / 2 x 3" Clamps

- 1 Using tools remove stock air box and OEM Clamps, put aside for later use.
 - 2 Place the 2.75" - 3" Silicon Reducer Hose onto the Air Flow Meter and clamp down with the OEM clamp.
 - 3 Disconnect and remove 1" hose from stock intake tube , and put aside
 - 4 Place a supplied Stainless Steel Clamp onto the 3" end of the 2.5"- 3" Reducer hose.
 - 5 Place Weapon*R Intake Tube into the 3" end of Reducer hose and clamp down Stainless Steel Clamp.
 - 6 Attach Weapon*R Filter to end of Weapon*R Intake Pipe, clamp down.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 7 Install the 3" coupler onto intake pipe, secure with supplied clamp.
 - 8 Install filter assembly onto the end of Weapon*R intake pipe, secure with OEM clamp.
 - 9 Install factory 1" hose onto 1" nipple on Weapon*R pipe using 1" hose provided as an adapter as shown in pic.
 - 10 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 11 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 12 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 13 Secure with washer and nut included in bracket kit.
 - 14 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 15 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 16 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**
Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



SW intake / SW filter kit show above. Dragon will just have Dragon filter. Install is identical!