



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 942-113 / Dragon Intake : 842-113**

Application : **1997- 2000 Hyundai Tiburon / Elantra 2.0L 4 CYL.**

Parts List : **One x Weapon*R Intake pipe for Dragon or Secret Weapon Intake.**

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

Two x Weapon*R Intake pipe for Hyper Intake only

1 x Weapon*R Air Filter / 2 x 10mm x 12" Hose / 1 x 15mm

3 x 2.5-3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
 - 2 Disconnect and remove the PVC / Air Recirculator hose from OEM intake and engine.
 - 3 Disconnect the MAF sensor harness, remove MAF sensor.
 - 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
 - 5 Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
 - 6 Insert the Weapon*R intake pipe into the 2.5-3" coupler, secure with clamp.
 - 7 Install the 2.5-3" coupler onto the end of the intake pipe, secure with clamp.
 - 8 Insert the MAF sensor into the 2.5-3" Coupler, secure with clamp.
 - 9 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
 - 10 Install the 10mm hose from kit to the Air recirculator valve to the Weapon *R intake pipe.
 - 11 Install 10mm line into port on intake pipe. Insert AIT sensor into 10mm vacume line.
 - 12 Install 15mm vacume port to intake pipe, and connect to port behind intake manifold.
 - 13 Install the Weapon*R Hyper filter onto the end of the MAF sensor.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 14 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
 - 15 Install filter assembly onto the end of MAF Sensor, secure with OEM clamp.
 - 16 Install U-shaped part of intake system bracket under the clamp on air filter.
 - 17 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
 - 18 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
 - 19 Secure with washer and nut included in bracket kit.
 - 20 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
 - 21 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
 - 22 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

