



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s Hyper Intake : 942-117 / Dragon Intake : 842-117 / 842-119

Application : 2003-08 Hyundai Tiburon/ Elantra 4cyl

Part #'s Hyper Intake : 942-118 / Dragon Intake : 842-118

Application : 2003-08 Hyundai Tiburon / Elantra V6

Parts List : 2 x Intake pipe / 1 x Air Filter / 1 x 10mm x 12" Hose / 2 x 3" coupler
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV hose from OEM intake and engine.
- 3 Unplug MAF sensor harness, remove MAF sensor from the OEM air cleaner box.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon*R intake pipe with the vacuum port into the 3" coupler, and secure with clamp.
- 7 Install another 3" coupler onto the end of the WR intake pipe with the vacuum port and secure with clamp.
- 8 Install MAF sensor into the 3" coupler just installed on the WR pipe with the vacuum port and clamp MAF down.
- 9 Install the 3" coupler onto the end of the MAF sensor, secure with clamp.
- 10 Install the 2nd intake pipe with no vacuum port into the 3" coupler on MAF sensor, secure with clamp.
- 11 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 12 Install the Weapon*R Hyper filter onto the end of the intake pipe if applicable.

Note: Dragon Filter Option : Disregard installation on Hyper filter.

- 13 Install 3" coupler onto Dragon air filter, secure with supplied clamp.
- 14 Install filter assembly onto the end of Weapon*R intake pipe, secure with clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

