



**CARB PENDING**

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part #'s **Dragon Intake: 842-120**

Application : **2006-2009 Hyundai Accent**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter 3" / 1 x 10mm x 12" Hose/ 1 X 3"-3" Coupler  
2 x 2.5"- 3" Coupler / 1 x 2.75"-2.75" Coupler / 1 x 3"-3" Coupler / 6 x 3" Clamp  
1 x ECU Bracket Relocation kit/ 1 x Intake System Bracket kit

- 1 Loosen clamps on OEM rubber intake pipe, Disconnect PCV hose, and remove OEM rubber tube
- 2 Disconnect Wire harness to MAF sensor.
- 3 Unbolt the 2 x 10mm bolts holding MAF to top air box assembly, remove MAF and put aside
- 4 Locate 2 x 10mm bolts holding ECU in place to side of airbox and remove bolts.
- 5 Remove bolts securing OEM air cleaner box assembly , and remove OEM airbox
- 6 Locate 2 x 10mm bolts holding ECU in place and remove, unclip ECU body clips. Set ECU aside
- 7 Using one of the ECU hold down bolts bolt ECU relocation bracket to the vehicle.
- 8 Slide ECU into the bracket and bolt down using 2 x 10mm long bolts. Holding ecu in place
- 9 Wipe the throttlebody clean of any grease, install the 2.75"-2.75" coupler onto throttlebody, secure with OEM clamp.
- 10 Insert Weapon\*R intake pipe into the 2.75" side of the coupler, secure with clamp.
- 11 With the MAF in hand install the 2.5"-3 " coupler onto the back side of the MAF and clamp down.
- 12 Install the other 2.5" -3" coupler on the MAF and clamp down
- 13 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.

**NOTE: If you don't have a MAF sensor then connect filter directly to pipe**

**Note: Secret Weapon Filter Option :**

- 14 Install Secret Weapon air filter onto 3" side of the 2.5"-3" coupler installed onto MAF , secure with supplied clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

