



CARB PENDING

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 903-111**

Application : **1989-94 Mitsubishi Eclipse NON-TURBO**

Parts List : 1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 1 x 10mm x 12" Hose
1 x 2.5"-3" Coupler / 1 x 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp

Note: Additional Parts needed when you have a Dragon Filter.

1 x 3" Coupler / 2 x 3" Clamps

- 1 Loosen clamps on OEM rubber intake pipe.
- 2 Remove PCV hose from OEM intake and engine.
- 3 Disconnect the MAF sensor harness, carefully remove OEM airbox,
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon*R intake pipe into the 2.5-3" coupler, secure with clamp.
- 7 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 8 Install the 3" coupler onto the intake pipe, Install the Weapon*R air filter into the OEM airbox.
- 9 Only using 2 of the OEM bolts, re-install the OEM airbox, Re-connect the MAF sensor harness.
- 10 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 11 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 12 Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Note: Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.

Picture show below: Intake with foam air filter inside OEM canister.



Intake install with filter insert inside enclosed OEM canister

