

Vehicle Type		FULL-SIZE VANS										COMPACT VANS					OTHER		
		Low-roof					Mid-/High-roof					Ford Transit Connect	Chevrolet City Express	Ram Promaster City	Mercedes Metris	Nissan NV200	KUV Service Bodies	Box Trucks	Trailers
		Ford Transit 130" WB	Ford Transit 148" WB	Ford E-Series	Chevrolet Express	GMC Savana	Nissan NV	Ford Transit 130" WB	Ford Transit 148" WB	RAM ProMaster (All Heights)	Sprinter								
Model Years	2015 & Later	2015 & Later	1992-2013	1996 & Later	1996 & Later	2011 & Later	2015 & Later	2015 & Later	2014 & Later	2007 & Later	2011 & Later	2010 & Later	2016 & Later	2015 & Later	2016 & Later	2014 & Later			
<b>Mandatory Mounting Kits for EZGLIDE2™ Drop-Down Ladder Racks</b>																			
2085-0-01											X	X	X	X	X				
2130-0-01 <sup>1</sup>	X <sup>1</sup>						X <sup>1</sup>												
2102-0-01		X						X											
2113-0-01						X				X <sup>2</sup>								X	X
2115-0-01									X										
2505																		X	
<b>EZGLIDE2™ Drop-Down Ladder Racks</b>																			
2261-3-01												X	X	X	X	X			
2265-3-01												X	X	X	X	X			
2267-3-01												X	X	X	X	X			
2271-3-01	X	X	X	X	X	X													
2275-3-01	X	X	X	X	X	X													
2277-3-01	X	X	X	X	X	X													
2291-3-01							X	X	X	X	X							X <sup>4</sup>	X <sup>4</sup>
2295-3-01							X	X	X	X	X						X <sup>3</sup>	X <sup>4</sup>	X <sup>4</sup>
2297-3-01							X	X	X	X	X							X <sup>4</sup>	X <sup>4</sup>
<b>Mounting Kits for Quick Clamp and All-Purpose Racks R=Recommended X=Mandatory</b>																			
2085-0-01											X	R	R	R	R	R			
2130-0-01 <sup>1</sup>	R <sup>1</sup>						R <sup>1</sup>												
2102-0-01		R						R											
2113-0-01						X				X <sup>2</sup>								R	R
2115-0-01									X										
<b>ALUMINUM QUICK CLAMP RACKS</b>																			
223-3-03												X	X	X	X	X			
224-3-03												X	X	X	X	X			
225-3-03												X	X	X	X	X			
233-3-03	X	X	X	X	X	X													X <sup>4</sup>
234-3-03	X	X	X	X	X	X													X <sup>4</sup>
236-3-03	X	X	X	X	X	X													X <sup>4</sup>
<b>ALUMINUM ALL-PURPOSE RACKS</b>																			
209-3-03	X	X	X	X	X	X	X	X	X <sup>5</sup>	X	X							X	X
2097-3-03	X	X	X	X	X	X	X	X	X <sup>5</sup>	X	X							X	X
218-3-03												X	X	X	X	X			
222-3-03												X	X	X	X	X			
<b>STEEL ALL-PURPOSE RACKS</b>																			
205-3	205-5		X	X	X														
216-3	216-5		X	X	X														
2056-3	2056-5		X	X	X														
210-3			X	X	X														

<sup>1</sup> This mounting kit will be available starting July, 2017. Until then, the 2102-0-01 can be substituted. See Product Update Bulletin 16-0008.

<sup>2</sup> If the Sprinter van has factory installed roof mounting rails, this kit is not necessary.

<sup>3</sup> Order a 70521 handle kit with each 2295-0-01 dropdown used.

<sup>4</sup> As there are many different styles of trailers, check for adequate rack clearances.

<sup>5</sup> Not recommended for 159" wheelbase or 159" extended wheelbase Promaster vans.

