

WeatherTech[®]

UnderLiner[™] Installation Instructions



- 1** Place UnderLiner[™] in the bed of your truck. Align contours and cutouts for the wheel wells to allow UnderLiner[™] to lay flat and smooth.



- 2** Secure by placing your rigid bed liner on top.

Backed by a Limited Lifetime Warranty



WARNING



**UnderLiner[™] is Designed for
Placement Under a Rigid
Drop-in Truck Bed Liner ONLY!**

DO NOT USE OR SECURE WITHOUT A BED LINER

Check out the collection of truck bed accessories we offer.