

WeatherTech®

Billet BumpStep™

HITCH MOUNTED BUMPER PROTECTION

Instructions



- 1** Slide the 2" square portion of your BumpStep™ into your 2" receiver with the grooved step surface facing upwards.



- 2** Align the BumpStep™ to the deepest hole position allowed by your receiver.



- 3** Insert the WeatherTech® hitch pin (or any commercially available hitch pin) to secure your BumpStep™ to the receiver.

Fully warranted to the original owner against defects in materials and workmanship for the lifetime of the product and specifically excludes damage caused by impacts, damage from car wash chemicals, etc.