I - Sheet Number WTBF28 Rev.A

WeatherTech®

Easy-On™ Stone & Bug Deflectors

Important Safety Information



- CAUTION Before driving, ensure that the hood shield is properly secured to vehicle.
- Do not use automatic "brush-style" car washes.
- . Do not use cleaning solvents of any kind.
- · Periodically check all components for tightness.

Contents

NOTE: Actual product may vary from illustration.



Hood shield



Bump On x4



Insert x2



Tools Required



Car Wash Supplies



Clean Towel



Phillips screwdriver



Socket wrench

Preparation Before Painting / Installation

- A trial fit is recommended to ensure proper positioning and fit.
- Check fit of parts before painting as we will not accept the return of modified or painted parts.
- Wash and dry your vehicle to remove any debris and/or dirt from the installation area.

Installation Steps

NOTE: Actual application may vary slightly from illustrations.





