

WeatherTech®

Side Window Deflector Instructions

Contents



(2) Front Side Window Deflectors



(2) Weatherstrip Clips

Warning!

Accessories that are not properly fitted can be dangerous. Read the instructions carefully before installation, and comply with the instructions at all times.

Tips for Proper Fit

- Check that the thin flange of each deflector is fully inserted into the window channel. The flange is designed to rest in the channel between the window glass and rubber seal.
- For windows with an automatic raising feature: Roll the window all the way up without activating the automatic feature. Leave the window all the way up for at least 12 hours to promote proper function.
- If windows are equipped with a safety feature that does not allow the window to close completely; sandwich the window with your hand and pull upward to raise the window. Leave the window closed for at least 12 hours to promote functionality.

Installation Instructions



1 Make sure that windows are clean and dry. Then, lower windows half way.



2 Place weatherstrip clips onto the bottom of the side window deflector as shown.



3 Lower the front of the deflector onto the weatherstrip as shown. The weatherstrip molding may differ from vehicle to vehicle.



4 With the deflector now resting on the weatherstrip, insert the machined flange into the window channel.



5 Bow the deflector outward to slip the rear flange into the window gasket.



6 Starting from the front of the part, begin tucking the flange into the window channel.



7 Carefully pull outward to set the deflector while rolling the window up slowly.



8 Repeat steps 1-7 on the passenger side of your vehicle. **CONGRATULATIONS!** Your WeatherTech® Side Window Deflectors have been properly installed.



Check out the collection of wind deflectors we offer.