

WeatherTech®

Side Window Deflectors

Installation Instructions

Chevrolet/GMC Suburban 92-current
Chevrolet Tahoe 92-current, GMC Yukon 92-current
Chevrolet Blazer full-size 92-94, GMC Denali 99-current
Chevrolet/GMC full-size pickup 92-current

1. Open front windows completely. Hold one of the deflectors up to the corresponding rear window for reference (Illustrations 1-4 refer to the driver's side rear window).
2. Peel back the weather-strip molding in the upper right-hand corner of the driver's side window opening (very easily done by hand) and insert the rear retainer onto the exposed metal flange of window frame, approximately 2" (52 mm) from the top of the window's weather-strip molding (Illustration 2). Push the weather-strip molding back into place. Peel back the weather-strip molding in the upper left-hand corner of the driver's window opening and insert the front retainer onto the exposed metal flange of the window frame approximately 1¼" (31mm) from the top of the window's weather-strip (Illustration 2). Push the weather-strip molding back into place.
3. Insert the deflectors rear vertical edge (just the opaque machined mounting flange) into the window channel in the upper right-hand corner of the driver's side window opening. Important Note: There is a small hole in the rear, vertical-end of the deflector. The tab in the center of the rear retainer will insert into this hole, thus supporting the deflector (Illustration 3). Grasp the rear-end of the deflector firmly with your right hand while guiding the front-end of the deflector upward into the front retainer until the opaque machined flange is fully inserted into the window channel. (If excess resistance is experienced sliding deflector into retainer, apply a dab of Vaseline® to backside of deflector where it contacts weather-strip.)
4. Prior to closing your window for the first time, insure that the Side Window Deflector is a) properly inserted into each retainer (Illustration 3), and b) the precision machined mounting flange is fully inserted into the window channel from front to rear. Carefully and slowly close and open you window at least 5 times. The deflector will be fully seated once the window is left in the closed position for at least 24 hours.

