

WeatherTech®

Side Window Deflectors

Installation Instructions

For Side Window Deflector part #'s: 70278, 71278, 72278, 73278, 74278

PLEASE NOTE: YOU MUST FOLLOW THESE INSTRUCTIONS TO INSTALL CORRECTLY.

For proper support of the WeatherFlectors™, window deflector clips must be installed. If the deflector clip is not inserted properly, the wind deflector may fit loosely and damage to the deflector may result.

1



Open drivers window. Grasp rubber window gasket with your fore finger and thumb, and peel back to expose window frame.

Installation is recommended at temperatures above 50° Fahrenheit.

2



With window frame exposed, insert clip onto vertical part of window frame, just below curved portion in corner. Clip should be placed approximately 2½ inches from top of rubber gasket (over spot weld).

3



Repeat steps one (1) through three (3) for passenger-side window and rear window installation. *Please note that rear window clip mounts to forward end of the window as shown in step 3.

Reinstall rubber gasket, pressing onto window frame, and into clip. The clip will now support the rubber gasket properly to allow for normal deflector installation.