

WeatherTech®


Side Window Deflector Instructions

WARNING Accessories that are not properly fitted can be dangerous. Read the instructions carefully before installation, and comply with the instructions at all times.

NOTE Deflector may take longer to acclimate below 60° F/16° C



1 Dry fit deflector on window before installing. Clean the installation area of the glass with the included alcohol wipe, allow to dry. **NOTE:** Glass must be cleaned for the Side Window Deflector to attach properly.



2 Remove the red tape backing from one end of the deflector to the other. Avoid touching the adhesive to keep it clean.



3 Carefully align deflector along the top of the window. Press the Side Window Deflector to the window, making sure the entire length of the tape makes contact with the window surface.



4 Press and hold deflector firmly in place for at least 30 seconds to ensure proper attachment to the window. **IMPORTANT:** Avoid rain or washing the vehicle for at least 72 hours to allow adhesion to set.