

WeatherTech®

BumpFrame®

License Plate Frame Mounting Instructions

TOOLS NEEDED • #2 Phillips Head Screwdriver • 7/16" Wrench

1. Remove and re-use your original mounting hardware to install your WeatherTech® BumpFrame® license plate frame.
2. Lay the WeatherTech® BumpFrame® face down on a soft or non-abrasive surface.
3. Position the license plate face down into the recessed area on the back of your BumpFrame®, noting that the BumpFrame® has the WeatherTech® logo along the bottom for proper positioning.
4. Carefully position your BumpFrame® and license plate assembly into place, and reinstall using your original mounting screws. Securely fasten BEING CAREFUL NOT TO OVER-TIGHTEN.

CONTENTS:

- BumpFrame®
- *Hardware Not Included*

CARE INSTRUCTIONS:

- Clean with soapy water or window cleaner
- Do not use abrasive pads, harsh detergents or degreasers on the BumpFrame®

