

WeatherTech®

PlateFrame® Mounting Instructions

TOOLS NEEDED • #2 Phillips Head Screwdriver • 7/16" Wrench

- 1) Remove the Click and Stay® screw covers from the mounting holes in the WeatherTech® PlateFrame™ by pushing them out from the rearward side.
- 2) Lay the WeatherTech® PlateFrame® face down on a soft or non-abrasive surface.
- 3) Position the license plate face down onto PlateFrame®, lining up the holes in the plate and the holes in the frame. Make certain that you have a proper fit between the license plate and the PlateFrame®.
- 4) Select the four mounting screws that are most appropriate for your vehicle (If your mounting location only uses 2 holes, then see step 4A FIRST). Carefully position your PlateFrame® /license plate assembly into place on your vehicle and using a #2 Phillips Head screwdriver, securely fasten with the screws you have chosen, **BEING CAREFUL NOT TO OVER-TIGHTEN.**
(4A) If the mounting location on your vehicle only uses two screws, then first select machine screws "E" and matching nuts from the hardware pack. Install these two screws through the PlateFrame™ / license plate assembly in the holes that **DO NOT** go to the mounting holes on the vehicle. Using a #2 Phillips Head screwdriver and a wrench, tighten the two nuts onto the end of each screw, locking the assembly together, **BEING CAREFUL NOT TO OVER-TIGHTEN.**
- 5) Finally, position the Click and Stay® screw covers over each screw on your PlateFrame® with the drain hole on the bottom and push firmly to snap each one into place.

CARE INSTRUCTIONS:

- Clean with soapy water or window cleaner
- Do not use abrasive pads, harsh detergents or degreasers on the ClearCover®

