

INSTRUCTIONS APPLICATION: 2001-07 FORD ESCAPE/MAZDA TRIBUTE/MERCURY MARINER

AUTOMOTIVE PRODUCTS, INC.

SA	FARI BA	R ASSEMBLY				
		30-0025 NT KIT 1155	(1)			(4)
ITEM	QTY	CONTE	NTS		TOOLS	
1	1	SAFARI BAR ASSEMBLY (PURCHASED SEPARATELY)			3/4" SOCKET	
2,3	2	BRACKET, PASSENGER (2) AND DRIVER (3)			3/4" WRENCH	
4	2	BOLT PLATE			10MM SOCKET	
5	2	1/2-13 X 2.00" HEX HEAD BOLT			RATCHET	
6	6	1/2" FLAT WAS	HER		TORQUE WRENCH	
7	6	1/2" LOCK WAS	SHER		UTILITY KNIFE	
8	4	1/2-13 HEX NU	Т			


STEP 1. Remove the contents from box and check for damage. Verify all parts are present. Read instructions completely before beginning.


Ford Escape and Mazda Tribute

- STEP 2. Remove one 6MM bolt from each side of lower airdam located outside of each tie down loop. Mercury Mariner
- STEP 2. Trim each side of the lower airdam level with the bottom of bumper to a distance of 6 1/8" in from the inside face of the tie down loops.
- STEP 3. Attach brackets to tie down loops using bolt plates and 1/2" fasteners as shown. Hand tighten. SEE FIGURE 2. NOTE: Brackets attach to inside face of tie down loop.
- STEP 4. Attach Safari Bar to brackets using 1/2" fasteners as shown. Hand tighten. SEE FIGURE 1.
- STEP 5. Make sure Safari Bar and brackets are properly aligned and tighten fasteners. Recommended torque values are 64 Ft. Lbs. for 1/2" fasteners.
- STEP 6. Reinstall 6MM bolts and torque to 6 Ft. Lbs.

FINISH PROTECTION

Westin products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish or wax that contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.







Shop for quality Westin products on our website.

Thank You for choosing Westin products.

Buy grille guards and bull bars in our online store.