



No Drill BUG DEFLECTOR

Installation Instruction: E

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the existing holes in your hood. (This will also help verify if you have the correct shield for your vehicle).
- 3) Place bugshield in position, ensuring it is centered and fits tight against the hood.
- 4) Line up holes in bugshield with existing holes. (Note: holes in bugshield may not lay directly over existing holes).
- 5) Place locking device into hole and firmly press until it clicks into place.
- 6) Slowly close the hood and check for sufficient clearance between the bugshield and the grill. **DO NOT HOLD BUGSHIELD WHILE CLOSING OR OPENING HOOD.**
- 7) **DO NOT ATTACH THE CLEAR BUMP-ONS TO THE SHIELD OR THE WARRANTY WILL BE VOIDED.** It is essential for the clear bump-ons to be attached to the vehicle hood or paint damage will occur. Use the alcohol prep pads to clean 6-8 areas behind the bugshield large enough to affix the bump-ons. Gently pull bugshield away from the hood and place bump-ons between hood and bugshield. Make certain the bump-ons are positioned to keep bugshield from contacting hood.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- 5935 Push Pin, 8-bump-ons, 1 Alcohol pad