



INSTALLATION INSTRUCTIONS

- 1) OPEN HOOD OF VEHICLE AND CLEAN THE FRONT HOOD AREA.
- 2) PLACE BUG SHIELD IN POSITION ENSURING IT IS CENTERED AND FITS TIGHT UP AGAINST THE HOOD.
- 3) HOLD EACH END OF BUG SHIELD SECURELY AGAINST FRONT OF HOOD, MARK THE POSITION OF THE HOLES AND REMOVE THE BUG SHIELD.
- 4) CAREFULLY DRILL THE MARKED HOLES WITH A 1/8" DRILL BIT.
IMPORTANT: TAKE CARE NOT TO DRILL THROUGH OR DAMAGE THE TOP OF THE HOOD.
- 5) REPLACE BUG SHIELD AND INSTALL IT USING THE SCREWS AND WASHERS SUPPLIED.
* DO NOT OVERTIGHTEN SCREWS.
* DO NOT USE A POWER SCREWDRIVER.
- 6) SLOWLY CLOSE THE HOOD AND CHECK FOR SUFFICIENT CLEARANCE BETWEEN THE BUG SHIELD AND THE GRILL.
* DO NOT HOLD BUG SHIELD WHEN CLOSING HOOD.
- 7) DO NOT ATTACH THE CLEAR RUBBER FEET TO THE BUG SHIELD OR THE WARRANTY WILL BE VOIDED. IT IS ESSENTIAL FOR THE CLEAR RUBBER FEET TO BE ATTACHED TO THE VEHICLE HOOD OR PAINT DAMAGE WILL OCCUR. USE ALCOHOL PREP PADS TO CLEAN 6 OR 8 AREAS BEHIND BUG SHIELD LARGE ENOUGH TO AFFIX CLEAR RUBBER FEET. GENTLY HOLD BUG SHIELD AWAY FROM HOOD AND PLACE CLEAR RUBBER FEET BETWEEN BUG SHIELD AND HOOD. MAKE CERTAIN THAT CLEAR RUBBER FEET ARE POSITIONED TO KEEP BUG SHIELD FROM CONTACTING HOOD.

CLEANING INSTRUCTIONS: WASH WITH LOTS OF WARM WATER AND A MILD SOAP SOLUTION USING A SOFT, CLEAN CLOTH OR SPONGE. USE OF CLEANERS NOT APPROVED FOR ACRYLIC, OR USE OF IMPROPER SOLVENTS COULD RESULT IN PERMANENT DAMAGE WHICH WILL NOT BE COVERED BY WARRANTY.

WARNING: BUG SHIELDS ARE MADE OF BREAKAGE RESISTANT MATERIAL, TO AVOID DAMAGE MACHINE CAR WASHES ARE NOT ADVISED.