



Platinum Series Bug Shield
No Drill BUG DEFLECTOR
Installation Instruction: J

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. (This will also help verify if you have the correct shield for your vehicle).
- 3) Place the bugshield in position, ensuring it is centered.
- 4) Carefully slide the clips over the bugshield plastic and the sheet metal of hood. **MAKE SURE THE BARBED SIDE OF THE CLIP SLIDES INTO THE PLASTIC SLOT.**
- 5) Slowly close the hood and check for sufficient clearance between bugshield and the grill. **DO NOT HOLD THE BUGSHIELD WHEN OPENING OR CLOSING HOOD.**
- 6) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- U Clips