



Platinum Series Bug Shield

No Drill BUG DEFLECTOR Installation Instruction: ZZ

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bug shield by holding it up to the hood. Note which rubber bumpers line up with the holes in your bug shield. (This will also help verify if you have the correct shield for your vehicle).
- 3) Remove the rubber bumpers that correspond with slots in the bug shield. Place the nylon insert squares (plugs) into these corresponding holes.
- 4) Place washer onto screw and, starting on the ends, apply slight pressure to the shield while screwing in (this will keep the other plugs from working themselves out).

DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.

- 5) After you are certain the two outside screws are secure, install the remaining screws.
- 6) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- 8435 Nylon Plugs, 4- #10 Black Washers, 4- 12 – 24 X 3/4 Screws