



## Platinum Series Bug Shield

### Installation Instruction: HH

Before you begin installation please note you have two different sets of screws. Two of them are noticeably bigger. The bigger set installs in the two inside holes.

- 1) Thoroughly clean front hood area. Open hood and clean underside where tape will adhere.
- 2) "Dry Fit" the bugshield by holding it up to the hood.  
(This will help verify if you have the correct shield for your vehicle).
- 3) Install the two center screws (using the two bigger screws) into the corresponding, pre-existing holes. **DO NOT OVER TIGHTEN.**
- 4) Hold bugshield securely in place and lower hood to determine that the shield is centered. Do so by "eyeballing" either end. Make adjustments as needed.
- 5) **VERY IMPORTANT:** Pull the outer tags toward the front of the vehicle until the contours of the shield match the contours of the hood.
- 6) For the two outside holes. Carefully drill a hole in the appropriate place with a 1/8" drill bit. Take care not to drill through or damage the top of the hood. Then install the screws with the grommets.

**IMPORTANT:** Take care not to drill through or damage the top of hood.

- 7) Using a screw driver install the last two screws.  
**DO NOT OVER TIGHTEN SHIELD.**
- 8) Close hood and tell all your friends about your **FANTASTIC** new shield from **WADE.**

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not proved for acrylic, or use of improper solvents could result n permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 x 1/2 BAS screws, 2- 5/16 washers, 2- #10 X1/2 phillips truss, 2- Grommets