



Platinum Series Bug Shield  
No Drill BUG DEFLECTOR  
Installation Instruction: QQ

The installation of this bug shield can be done by a single individual, but it is not recommended.

- 1) Thoroughly clean front hood area.
- 2) Open Hood.

Some vehicles have a black plastic insert that has to be removed before installation. With a screw driver CAREFULLY remove insert to reveal the remaining bolts.

- 3) Remove the bolts from the two extended grill brackets using a 10mm socket.
- 4) Then remove the bolts from the rest of the grill. Remove grill.
- 5) Place the nylon insert squares (plugs) into the holes that correspond with the holes on the shield.
- 6) Place washer onto screw and, starting on the ends, apply slight pressure to the shield while screwing in (this will keep the other plugs from working themselves out).
- 7) Position the bugshield in the center of the hood and reinstall the two extended grill brackets first and then the remaining bolts.

**DO NOT OVER TIGHTEN BOLTS.**

- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- PO129 Nylon Nuts, 2- #10 Black Washers, 2- 10/24 X 5/8 Screws