



## Platinum Series Bug Shield BUG DEFLECTOR

### Installation Instruction: SS

BEFORE YOU BEGIN INSTALLING THIS SHIELD, PLEASE NOTE THAT THE SHIELD INCLUDES BOTH TAPE AND INSTALLATION HARDWARE. DETERMINE WHERE THE TAPE WILL ADHERE TO THE VEHICLE AND THOROUGHLY CLEAN THE CONTACT AREA WITH MILD SOAP AND WATER. THEN MAKE SURE IT IS CLEAN USING THE ALCOHOL PADS PROVIDED.

- 1) Thoroughly clean front hood area.
- 2) "Dry Fit" the bugshield by holding it up to the hood.  
(This will help verify if you have the correct shield for your vehicle).
- 3) Insert the two rubber well-nuts into the two outside holes (that correspond with the holes on your shield).
- 4) Place washer on well-nut screw and install shield onto hood.  
(Install tip: The well-nut is a compression unit. It may not feel like you are screwing in anything at all for a moment. The secret is to keep enough pressure on the shield so the well-nut does not fall out).
- 5) Mark the position of the two center holes.
- 6) Carefully drill the marked holes with a 1/8" drill bit.  
IMPORTANT: Take care not to drill through or damage the top of hood.
- 7) By hand, install two center holes using the screws and rubber washers supplied.  
Do not over tighten.
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 8/32 Well Nut, 2- 8/32 x 5/8 Screw, 2- #10 Black Washer, 2- #10 X 1/2 Phillip Truss,  
2- Grommets