



Platinum Series Bug Shield
No Drill BUG DEFLECTOR
Installation Instruction: B

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the plastic plugs on your vehicles weather stripping. (This will also help verify if you have the correct shield for your vehicle).
- 3) Remove ONLY the plastic plugs from the weather-stripping that corresponded with the holes in your bugshield (using a pair of pliers or a fork).
- 4) Place shield UNDER the weather-stripping and insert nylon pushpin. Be sure to go through the shield, weather-stripping and into the hole. Before locking push pin in place by pushing in the nylon plugs make certain the shield is properly centered by "eyeballing" the two ends (you may need to move the shield to either the left or right).
- 5) Push in Locking Pin. Install Tip: It is possible to push the pin in with only the use of your hand. But, if you are unable to do this, due to the tight fit of the locking pin, we would suggest LIGHTLY tapping it in with the use of a hammer.
- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- 5935 Push Pin