



Platinum Series Bug Shield  
No Drill BUG DEFLECTOR  
Installation Instruction: R

The installation of this bug shield can be done by a single individual, but it is not recommended.

- 1) Thoroughly clean front hood area.
- 2) Open Hood.
- 3) Remove the bolts from the two extended grill brackets using a 10mm socket.
- 4) Then remove the bolts from the rest of the grill. Remove grill.
- 5) Position the bugshield in the center of the hood and reinstall the two extended grill brackets first and then the remaining bolts.

**DO NOT OVER TIGHTEN BOLTS.**

- 6) Now, insert the two well-nut into to two outside holes (that correspond with the holes on your shield).
- 7) Place washer on well-nut screw and install shield onto hood. (install tip: The well-nut is a compression unit. It may not feel like you are screwing in anything at all for a moment. The secret is to keep enough pressure on the shield so the well-nut does not fall out).

- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 8/32 Well Nut, 2- 8/32 x 5/8 Screw, 2- #10 Black Washer