



Platinum Series Bug Shield Installation Instruction: II

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. Note which holes in your bugshield line up with the existing holes in your hood. (This will also help verify if you have the correct shield for your vehicle).
- 3) You should have two separate sets of hardware. Comprising of three push pins and two screws. Install the larger set of push pins into the three center holes.
- 4) For the two outside holes. Carefully drill a hole in the appropriate place with a 1/8" drill bit. Take care not to drill through or damage the top of the hood. Then install the screws with the grommets.

DO NOT OVER TIGHTEN.

- 5) Slowly close the hood and check for sufficient clearance between the bugshield and the grill. **DO NOT HOLD BUGSHIELD WHILE CLOSING OR OPENING HOOD.**
- 6) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

3- 14010 Push Pins, 2- Phillips #10 x1/2 pan head screws, 2- grommets