



Platinum Series Bug Shield
No Drill BUG DEFLECTOR
Installation Instruction: S

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood. (This will also help verify if you have the correct shield for your vehicle).
- 3) Now, with the screws and washers provided, attach shield by screwing into the pre-existing holes. **DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**
- 4) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right).
- 5) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- #14 X1/2 Panhead SMS, 4- Black Grommets