

INSTALLATION INSTRUCTIONS

Platinum Oval Step Bar Set

APPLICATION: 2014+ Chevrolet Silverado 1500 & GMC Sierra 1500 Double & Crew Cab 2015+ Chevrolet Silverado 2500/3500 & GMC Sierra 2500/3500 Double & Crew Cab

Part Numbers: 21-3810, 21-3815, 21-3820, 21-3825, 21-3850, 21-3855, 21-3860, 21-3865


| ITEM | QUANTITY | DESCRIPTION | TOOLS NEEDED |
|------|----------|---|---------------------------|
| 1 | 1 | DRIVER SIDE STEP BAR (CLEAR WRAPPING) | RATCHET |
| 2 | 1 | PASSENGER SIDE STEP BAR (PINK WRAPPING) | 3/4" SOCKET |
| 3 | 2 | FRONT MOUNTING BRACKET | 21MM SOCKET |
| 4 | 1 | DRIVER SIDE CENTER MOUNTING BRACKET | 5MM HEX KEY (INCLUDED) |
| 5 | 1 | PASSENGER SIDE CENTER MOUNTING BRACKET | |
| 6 | 2 | REAR MOUNTING BRACKET | TORQUE WRENCH |
| 7 | 4 | 1/2" X 2" HEX CAP SCREW | |
| 8 | 4 | 1/2" SPLIT LOCK WASHER | |
| 9 | 4 | 1/2" FLAT WASHER | |
| 10 | 4 | M10 X 35MM BUTTOM HEAD CAP SCREW | |
| 11 | 4 | M10 INTERNAL TOOTHED LOCK WASHER | |
| 12 | 4 | M10 FLAT WASHER | |

- 1. Remove contents from box, verify if all parts listed are present and free from damage. Carefully read and understand all instructions before attempting installation.
- 2. Start installation at the driver side. Locate the front cab mount. Remove the M14 body mount bolt from the cab mount. Install the front mounting bracket with the factory washer on the top side of the bracket. Do not fully tighten at this time. FIGURE 2
- 3. Repeat step 2 for the driver side center mounting bracket & the rear mounting bracket. Do not interchange the body mount bolts. They are sized specifically to each location.
- 4. Attach the driver side step bar assembly to the front mounting bracket using the provided 1/2" fasteners. Repeat the same for the rear mount.
- 5. The center mounting bracket is attached to the step bar using the provided (x2) M10 button head screws, (x2) lock washers, then (x2) flat washers.
- 6. Align the step bar as desired. The slots in the mounting brackets allow in & out adjustment.
- 7. The recommended torque values for each fastener type are as follows. M14 body mount bolts to 95 ft-lbs, 1/2" fasteners to 65 ft-lbs, and the M10 fasteners to 30 ft-lbs.

CARE INSTRUCTIONS

- REGULAR WAXING IS RECOMMENDED. DO NOT USE ANY TYPE OF POLISH OR WAX THAT MAY CONTAIN ABRASIVES
- STAINLESS STEEL PRODUCTS CAN BE CLEANED WITH MILD SOAP AND WATER. STAINLESS STEEL POLISH SHOULD BE USED TO POLISH SMALL SCRATCHES.
- GLOSS BLACK FINISHES SHOULD BE CLEANED WITH MILD SOAP AND WATER

1500 MODELS



2500/3500 MODELS

