

## INSTALLATION INSTRUCTIONS


APPLICATION: 2007-08 TOYOTA TUNDRA D-CAB & CREW MAX

## **AUTOMOTIVE PRODUCTS, INC.**

MOUNT KIT **22-1665** 

CHROME **22-0020**, **22-0040** 

BLACK **22-0025, 22-0045** 



ITEM	QTY	CONTENTS	TOOLS
1,2 3 4 5 6 7 8 9 10 11	2 2 2 2 2 16 16 16 16 16	STEP BAR, PASSENGER (1) AND DRIVER (2) (SOLD SEPARATELY) FRONT BRACKET FRONT/CENTER BRACKET REAR/CENTER BRACKET REAR BRACKET M8-1.25 X 30MM HEX HEAD BOLT 3/8" FLAT WASHER 3/8" LOCK WASHER 1/4-20 X .75 T-HEAD BOLT 1/4" FLAT WASHER 1/4-20 NYLON INSERT LOCK NUT	13MM SOCKET 13MM WRENCH 7/16" SOCKET RATCHET TORQUE WRENCH

- STEP 1. Remove the contents from box and check for damage. Verify all parts are present. Read instructions completely before beginning.
- STEP 2. Determine front, front center, rear center and rear brackets. Rear/center bracket has 1 identification hole and rear bracket has 2 identification holes.
- STEP 3. Attach drivers side brackets to underside of body panel using two M8-1.25 x 30mm hex head bolts, 3/8" flat washers, and 3/8" lock washers per bracket. Hand tighten. **SEE FIGURE 1.**
- STEP 4. Slide T-head bolts on step bar as shown (4 per slot, 8 per bar). Place step bar on saddle with long step pad forward and end cap screw facing inward. Assemble with 1/4" fasteners. **SEE FIGURES 2 AND 3.**
- STEP 5. Make sure step bar and brackets are properly aligned with vehicle and tighten fasteners.

  Recommended torque values are 8mm fasteners to 22 FT.LBS. and 1/4" fasteners to 7 FT. LBS.
- STEP 6. Repeat installation for passenger side.

## FINISH PROTECTION

Westin products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnauba) on a regular basis. The use of any soap, polish or wax that contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.

