



AUTOMOTIVE PRODUCTS, INC.

# INSTALLATION INSTRUCTIONS

APPLICATION: E-SERIES STEP BAR & PLATINUM OVAL STEP BAR / 2015 & UP FORD F-150  
APP PART # 21-3940, 23-3940, 21-3940, 23-3945

ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	DRIVER SIDE OVAL STEP BAR ASSEMBLY	RATCHET
2	1	PASSENGER SIDE OVAL STEP BAR ASSEMBLY	UTILITY KNIFE
3	1	DRIVER SIDE FRONT MOUNTING BRACKET	3/4 SOCKET
4	1	PASSENGER SIDE FRONT MOUNTING BRACKET	13MM SOCKET
5	1	DRIVER SIDE REAR MOUNTING BRACKET	TORQUE WRENCH
6	1	PASSENGER SIDE REAR MOUNTING BRACKET	SOCKET EXTENS.
7	4	1/2" HEX HEAD SCREW (YELLOW ZINC)	
8	4	1/2" FLAT WASHER (YELLOW ZINC)	
9	4	1/2" SPLIT LOCK WASHER (YELLOW ZINC)	
10	12	M8 HEX NUT (YELLOW ZINC)	
11	12	M8 FLAT WASHER (YELLOW ZINC)	
12	12	M8 SPLIT LOCK WASHER (YELLOW ZINC)	
13	12	M8 SQUARE PLASTIC POLY RETAINER	

**ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING .**

1. Remove contents from box, verify if all parts listed are present and undamaged. Carefully read and understand all instructions before attempting installation.
2. Locate factory welded bolts on the rocker panel, See Figure 1.
3. Thread M8 square plastic poly retainer onto factory bolts for driver side. Repeat for passenger side, see Figures 2 and 3. (Note: The plastic poly retainers are necessary to prevent reaction between supplied steel equipment and aluminum rocker panel.)
4. Loosely install driver side mounting brackets with supplied M8 hardware. Repeat for passenger side, see Figures 4 and 5.
5. Loosely install step bar to driver side mounting brackets using supplied 1/2" hardware. Repeat for passenger side, see Figures 6 and 7.
6. Align and adjust as necessary then torque: M8 hardware to 15-18 ft-lbs., and 1/2" hardware to 50-55 ft-lbs.



