









INSTALLATION INSTRUCTIONS

APPLICATION: 07-13 CHEVY SILVERADO/ GMC SIERRA 1500/2500/3500 SERIES EXTENDED CAB

AUTOMOTIVE PRODUCTS, INC.



<div>MOUNT KIT 27-1745</div> <div>MOLDED STEP BOARDS 27-0010 27-0015</div>		<div>SURE-GRIP OPTIONAL LIGHT KIT 27-6000</div> <div>27-6130 27-6135 27-6530</div>	<div><div>1</div></div>	<div><div>2</div></div>	<div><div>3</div></div>
ITEM	QTY	CONTENTS		TOOLS	
1	2	STEP BOARD (PURCHASED SEPARATELY)		13MM SOCKET 13MM WRENCH 1/2" SOCKET RATCHET TORQUE WRENCH	
2	5	MOUNT BRACKET			
3	1	THIN MOUNTING BRACKET (FOR DIESELS WITH UREA TANK)			
4	12	M8-1.25 X 30MM HEX HEAD BOLT			
5	6	M8-1.25 HEX NUT			
6	6	M8-1.25 EXTRUDED U-NUT			
7	12	5/16-18 X .75 SQUARE HEAD BOLT			
8	30	5/16" FLAT WASHER			
9	12	5/16" LOCK WASHER			
10	12	5/16" LOCK NUT			

- STEP 1. Remove contents from box and check for damage. Verify all parts are present. Read instructions completely before beginning. It is strongly recommended to install the Sure Grip Gap Strip for these vehicle applications.
- STEP 2. Attach mounting brackets as shown. SEE FIGURE 7 AND 8. For late model diesel trucks SEE PG. 4 for the front passenger side mounting bracket.
- STEP 3. Insert square head bolts as shown (3 per slot, 6 per Step Board/Running Board). SEE FIGURES 2 AND 3.
NOTE: For lighted boards, run wiring harness prior to attaching board to brackets (refer to Step 6). Run longer wire harness on passenger side.
- STEP 4. For Sure-Grip Running Boards, slide closure strip as shown. Set lights (if purchased) in appropriate location. Attach to Sure-Grip Running Board as shown. SEE FIGURE 1. Drill hole through plastic strip and run wires as shown. SEE FIGURE 4.
- STEP 5. Attach board to brackets as shown. Make sure board and brackets are properly aligned and tighten fasteners. Recommended torque values are 10 FT.LBS. for 5/16" square head fasteners and 23 FT.LBS. for 8MM fasteners. SEE FIGURE 5.
NOTE: For lighted version of Molded Step Board, remove plastic cover from each end of under side of board. Proceed to Steps 6-7.
- WARNING: INSTALLING LIGHT HARNESS REQUIRES SPLICING INTO VEHICLES ELECTRICAL SYSTEM. WESTIN RECOMMENDS USING A PROFESSIONAL FOR THIS INSTALLATION. NOTE: AVOID AREAS OF EXCESSIVE HEAT, VIBRATION, PINCH OR ROTATION WHEN SECURING HARNESS TO VEHICLE. CAUTION: ALWAYS USE A FUSED(+) POSITIVE SUPPLY SOURCE. UNDERCOAT SEAL FOR HARSH WEATHER.
- HINT: Molded Step Boards: For longevity, check rubber seals before installation. Rubber grommets around red and blue wires going into rear sockets, should be inserted and recessed about 1/4". NOTE: Remove bulbs and apply white grease into sockets and replace bulbs. Apply RTV Silicone where lights go into socket. Install lights and run wire loom as shown. SEE FIGURE 3. For Sure-Grip Running Boards, run wire loom down center as shown. SEE FIGURE 2.
- STEP 6. Determine whether your vehicle has a positive or negative switching courtesy system or an auxiliary light source (most Fords). Obtain an accurate wiring diagram for your vehicle's courtesy light system.
For positive and negative switching:
Locate a pass-through point (usually under carpet at driver side door sill) for the wire harness. Locate main courtesy wire (usually wire lead to dome light). NOTE: If you do not use the main courtesy wire, lights will only function when one door is open. Route wire harness so that the 2 female connections (from step board) are nearest to pass thru point.*Connect opposite step board lead to either connection. Connect the splicing lead to remaining female socket and route one wire thru pass thru point. SEE FIGURE 6.
- VERY IMPORTANT - Double check that your system has positive or negative switching.
For positive switching only: Connect positive wire to main courtesy system, (usually wire lead to dome light). TEST CONTINUITY BEFORE CONNECTING BY OPENING AND CLOSING ALL DOORS. Ground remaining wire.
For negative switching only: Connect negative wire to main courtesy system, (usually wire lead to dome light but sometimes from dome light to courtesy ECU). TEST GROUND CONTINUITY BEFORE CONNECTING BY OPENING AND CLOSING ALL DOORS. Connect remaining wire to battery using a 5A fuse.
**Be sure that you have not routed any wires near moving parts (i.e.. driveshaft) or near any heat generating source (i.e.. transmission, engine, exhaust).
- Auxiliary Light source:
Locate auxiliary light source connection under vehicle (usually attached to back side of front or rear fender well (refer to vehicles owners manual). SEE FIGURE 6. TEST SOURCE BEFORE CONNECTING. Connect splicing leads to aux light source. test step board lights for proper function by opening and closing doors.
- STEP 7. Under-coat board, brackets and electrical wires, connections and lenses for harsh weather conditions. Reinstall plastic cover on



FOR DIESEL EXHAUST FLUID TANK EQUIPPED APPLICATIONS, THE TANK MUST BE LOWERED TO INSTALL THE PASSENGER SIDE FRONT MOUNTING BRACKET.

- STEP 1 Remove the D.E.F. tank cover by removing the three fasteners along the front edge, then lift the cover off the hooks in the rear and push it towards the frame.
- STEP 2 Disconnect the fill hose from the front of the tank.
- STEP 3 Remove the support strap closest to the front of the vehicle by removing the bolt between the tank and rocker panel. The strap then can be unhooked and dropped from the rear.
- STEP 4 Loosen the rear strap to drop the front of the tank approximately 4".
- STEP 5 Install the passenger side diesel bracket by using the hardware shown. Additional clearance may be had by removing the two fasteners holding the front upper strap to the frame.
- STEP 6 Reinstall the DEF tank and support straps.
- STEP 7 Trimming of the D.E.F. cover is recommended before attempting to re-install it.






FIGURE 4




FIGURE 5




FIGURE 6




FIGURE 7
DRIVER SIDE




FIGURE 8

REAR MOUNT LOCATION