

INSTALLATION INSTRUCTIONS


APPLICATION: 1999 - UP FORD RANGER 4 - DOOR

1999 - UP MAZDA TRUCK 4 - DOOR

AUTOMOTIVE PRODUCTS, INC.


STEP BAR ASSEMBLIES


23-1550 23-1555





QTY	PARTS KIT CONTENTS DESCRIPTION	TOOLS REQUIRED
1 1 1 1 1 1 1 1 1 1 4 4 4 4 12 20 12 8	STEP BAR - DRIVER SIDE STEP BAR - PASSENGER SIDE FRONT BRACKET - DRIVER SIDE FRONT BRACKET - PASSENGER SIDE REAR BRACKET - DRIVER SIDE REAR BRACKET - PASSENGER SIDE NUT PLATE ASSY - DRIVER SIDE NUT PLATE ASSY - DRIVER SIDE SUPPORT STRAP - DRIVER SIDE SUPPORT STRAP - PASSENGER SIDE BACKING PLATE ASSY - DRIVER SIDE BACKING PLATE ASSY - DRIVER SIDE BACKING PLATE ASSY - P ASSENGER SIDE 1/2 -13 X 2.50' LG. HEX HEAD BOLT 1/2" FLAT WASHER, ZINC PLATED 1/2" LOCK WASHER, ZINC PLA TED 3/8 -16 X 1.25' LG. HEX HEAD BOLT 3/8" FLAT WASHER, ZINC PLATED 3/8" LOCK WASHER, ZINC PLA TED 3/8" LOCK WASHER, ZINC PLA TED 3/8" LOCK WASHER, ZINC PLA TED	3/4" SOCKET 9/16" SOCKET 9/16" WRENCH TORQUE WRENCH RATCHET
		I


- STEP 1. Remove the contents from the box and check for any damage. Verify all parts against parts list.
- STEP 2. Read and understand instructions completely before beginning installation.
- STEP 3. Install Front Brackets using hardware supplied and by following Figures 1 through 3.
- STEP 4. Mount Backing Plate to vehicle as shown in Figure 4.
- STEP 5. Attach Rear Bracket to vehicle and Backing Plate as shown in Figure 5.
- STEP 6. Attach Step Bars to Mounting Brackets.
- STEP 7. Tighten and torque 3/8" Fasteners to 30 FT. LBS. And 1/2" Fasteners to 65 FT. LBS.











NOTE: INSTRUCTIONS SHOWN ARE FOR PASSENGER SIDE INSTALLATION. DRIVER SIDE INSTALLATION IS OPPOSITE.

Finish protection - Westin products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax (pure carnauba, for example) on a regular basis. The use of cleaner wax or any compound which contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.