




SIGNATURE OF QUALITY

AUTOMOTIVE PRODUCTS, INC.

INSTRUCTIONS

APPLICATION: 2006-08 HUMMER H3



ITEM	QTY	CONTENTS	TOOLS
1,2	2	STEP BAR, PASSENGER (1) AND DRIVER (2)	17MM SOCKET RATCHET TORQUE WRENCH
3,4	2	FRONT MOUNT BRACKET, PASSENGER (3) AND DRIVER (4)	
5,6	2	REAR MOUNT BRACKET, PASSENGER (5) AND DRIVER (6)	
7	8	M10-1.5 X 35MM HEX HEAD BOLT	
8	8	M10 FLAT WASHER	
9	8	M10 LOCK WASHER	
10	8	M8-1.25 X 25MM BUTTON HEAD BOLT	
11	8	M8 INTERNAL TOOTH LOCK WASHER	

- STEP 1. Remove the contents from box and check for damage. Verify all parts are present. Read instructions completely before beginning.
- STEP 2. Locate driver side mounting locations on vehicle. Attach mount brackets as shown. **SEE FIGURE 1.** Repeat for passenger side. It may be necessary to clean out mounting holes on frame with a 10mm tap.
- STEP 3. Attach driver side step bar to cradles with the *Westin* logo facing outward as shown. Assemble with M8 fasteners. Hand tighten. **SEE FIGURE 2.**
- STEP 4. Make sure step bar and brackets are properly aligned and tighten fasteners. Recommended torque values are 31 Ft. Lbs. for M10 fasteners and 16 Ft. Lbs. for M8 fastener.
- STEP 5. Repeat installation for opposite side.

FINISH PROTECTION

Westin products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax, (e.g. Pure Carnuba) on a regular basis. The use of any soap, polish or wax that contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.

FIGURE 1 INSTALLATION VIEW OF DRIVER SIDE SHOWN, PASSENGER SIDE OPPOSITE

