

Application:

HYUNDAI VELOSTER:

*Always refer to current catalogue for complete application listing.*Kit Contents:

1x 18mm fixed swaybar.
4x mounting bolts.
4x flat washers.
4x nyloc nuts.

- This installation can be carried out on the ground without the aid of a hoist - a hydraulic jack and stands will suffice.
- The rear springs need to be removed - this requires unbolting the lower shock mount.



- Once the lower shock mount is unbolted, slowly raise the body - careful to not stretch the brake lines.

- Remove the rear coils as per above image.
- Once the coils have been removed, position the supplied bolts in the spring seat as below image.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Fitting Instructions

Rear Swaybar Kit

Code: Z5280

Application:

HYUNDAI VELOSTER:

Always refer to current catalogue for complete application listing.

Kit Contents:

1x 18mm fixed swaybar.
4x mounting bolts.
4x flat washers.
4x nyloc nuts.

- Bolt the swaybar to the spring seats using the supplied washers and nyloc nuts.



- Once hardware is tight, re-fit coils and lower shock mount.

- Tighten the lower shock mount at ride height.
- Re check all bolts after initial 100km's.



N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.