

Application:

HOLDEN CRUZE:  
2012 - ON

*Always refer to current catalogue for complete application listing.*

Kit Contents:

1 x 22mm swaybar.  
2 x threaded boss.  
2 x 10.9 class bolts.  
2 x flat washers.

- Raise vehicle evenly and safely support.
- Using a suitable jack stand, support the rear axle beam and undo the lower shock bolts.
- Once the lower bolts have been removed, lower the beam down and remove the rear coils.
- Remove the lower rubber spring pad.
- Remove the lower spring locator with a suitable punch (refer below images).
- Position supplied threaded boss in spring seat.



*Unbolt lower shock mount and remove coils.*



*Punch out spring locator*



*Position supplied threaded boss.*

# Fitting Instructions

## REAR SWAYBAR KIT

Code: Z5265

### Application:

HOLDEN CRUZE:  
2012 - ON

*Always refer to current catalogue for complete application listing.*

### Kit Contents:

1 x 22mm swaybar.  
2 x threaded boss.  
2 x 10.9 class bolts.  
2 x flat washers.

- Refit rubber spring pads and coils.
- Confirm threaded boss is properly located.
- Using a suitable jack, raise the rear beam and bolt up lower shock mount.
- Bolt the swaybar into position using the supplied bolts and washers.
- We suggest using a small amount of Loctite to the threads before tightening.
- Re check bolts after initial 100kms driven.



*Re fit spring pads and coils*



*Confirm threaded boss is properly located.*

