

### Application:

- Nissan Skyline R35 Series

Always refer to current catalogue for complete application listing.

### Contents:

- 2 x 67244 Bushes
- 2 x F1207 Aluminium tubes
- 1 x Grease satchet

### Fitting Instructions:

Please read complete fitting instructions and check kit components prior to fitment.

These instructions are to be used in conjunction with the workshop manual, and it is recommended that all work be carried out by a qualified technician.

1. Raise and support the vehicle on chassis stands.
2. Remove the road wheels from vehicle.
3. Remove the two lower ball joint nuts.
4. Remove the shock absorber lower mounting bolt from the lower control arm.
5. Remove the sway bar link.
6. While supporting the wheel hub assembly remove the two lower control arm bolts and arm from the vehicle.
7. Remove the OE lower control arm from the vehicle.
8. Using a suitable press and press plate, remove the OE bush & housing from the arm.
9. Ensure the arm face is clean of burrs and press the supplied F1207 tube onto the arm until seated.
10. Press the OE bush out of the alloy housing.

**Note:** Install the supplied 67244 bush into the aluminium OE housing as indicated in the pictures. The bush can be installed into the alloy housing in varying positions dependant on outcome expected.

11. Apply liberal amounts of grease supplied to the running surface of the bush.
12. Re-install lower control arm to the vehicle and tension all bolts to manufacturers torque specifications.
13. Re-fit road wheels and settle vehicle on the ground.
14. Carry out wheel alignment as required.

**Note:** It is recommended to re-tension all bolts in approx 100km's of distance travelled.

