WHITELINE Instruction Sheet

GEARBOX MOUNT INSERT Application: Ford Mustang - GT and Boss 302

2011 - on

N.B: This instruction sheet should be used in conjunction with the workshop manual





- Evenly raise the vehicle and safely support
- Support the gearbox prior to removing the crossmember.
- Un bolt the crossmember and remove from the vehicle.





- Push the insert into position from the front of the mount.
- The insert should sit neatly in the voided rubber mount.
- Re fit the crossmember to the vehicle.

N.B: It is recommended that a licenced workshop or tradesperson carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.

Z5312