

Fitting Instructions KSB630

WHITELINE

Flat out

Code: Z294

Application: Subaru Liberty - BL/BP, 09/03 - 05. [Front strut tower brace.](#)
Refer to catalogue for exact listings.

Contents:

1 x complete strut tower brace assembly.

Fitting:

1. Remove end plates from centre section of strut brace and loosely place in their position on both strut tops.
2. In order to make the fitment of KSB630 front strut tower brace easier, it is recommended to tighten both strut brace end plates down into place, this will bend the end plates into the required shape.
3. Release the tension of the mounting nuts to allow the end plates to be re-positioned if required, this will ease the fitment of the centre brace section.
4. Adjust the length of the alloy bar and loosely fit to the centre bar section to the end plates. Do not pre-load the strut brace.
5. Tighten strut brace end plate brackets to strut top. Secure alloy bar section of strut brace into desired position ensuring sufficient clearance from engine and any moving components.
6. With vehicle at normal ride height and on level ground, securely tighten the strut brace centre bar to end brackets.

NOTE: Adjustment provided is to be used for ease of fitment. Do not use the adjustment to pre-load the strut brace.



Warning: Please drive carefully while you accustom yourself to the changed vehicle behaviour.