

13557

06-UP

DODGE

CHARGER [CHIN SPOILER](#)

CONTENTS:

- | | |
|---------------------------|------------------------|
| 1 - Chin Spoiler | 8 - 5/16" Lock Washers |
| 8 - 5/16" Hex Bolts | 8 - 5/16" Hex Nuts |
| 16 - 5/16" Fender Washers | |

TOOLS REQUIRED FOR INSTALLATION

- 3/8" Drill Bit
- 1/2" Wrench
- Marker
- Drill

INSTALLATION & HARDWARE MOUNTING INSTRUCTIONS

Please read thoroughly before beginning

1. Fit your new chin spoiler to the front bumper and position in desired location.
2. Using part as a template, mark eight (8) hole locations in the front bumper.
3. Drill eight 3/8" holes in the marked locations.
4. Install bolts, fender washer through the chin spoiler and bumper cover into fender washer lock-washers, nuts.
5. Tighten ALL hardware. **DO NOT OVER-TIGHTEN.**

NOTE:

This chin spoiler will reduce available ground clearance in front of the vehicle. Use caution when approaching driveways, speed bumps, parking blocks or similar items on the road.

