

BATTERY PACK

by King Penn Industries Inc.

Instructions are for Battery Pack Only. Please refer to main instructions for installing the WindRestrictor. This diagram should be used in place of the single color lighting instructions that come with all illuminated orders but you will still need to refer to the main instructions for mounting the product.



Our WindRestrictor's come in various shapes and sizes. When installed they will always have the RGB light strip placed directly below the glass. Please refer to model specific installation instructions for proper mounting of the device and wiring placement in the vehicle.

To utilize your battery pack simply connect the red wire from pack to red wire from LED lighting strip then do the same with black wire. Make sure the wires are taped up so that they do not touch each other. Put battery in the holder and turn switch to the "ON" position. You should see illumination at night.

CLOSE UP VIEWS OF 9V BATTERY PACK

