

Installation instructions

2. Remove the lefthand and righthand cowl trim pieces.
3. Note position of wiper blades on windshield.
4. Remove the wiper arm nut covers, then the nuts and wiper arms.
5. Remove the pin type retainers attaching the cowl cover to the cowl, Fig. 1.
6. Release the righthand corner of the cabin air filter by pushing on the retaining clip.
7. Release the lefthand corner of the cabin air filter, then lift the filter from the cowl opening, Fig. 2.
8. Install the new cabin air filter element through the passenger side cowl opening. If filter is equipped with air flow markings, ensure the marking is facing the proper direction.
9. Install the cowl cover. Ensure all the retainers are properly attached.
10. Install the wiper arms. Secure the wiper arms with nuts, then install nut covers.
11. Install the lefthand and righthand cowl trim pieces.
12. Close the hood.

