


Instructions

1. Removing OEM Hardware and Installing Mounts

This installation will start with the Jeep brand tool set that was included with your JL/JT at purchase. Using the torx head bit remove the 2 fasteners on the cowl section from both sides of the vehicle shown in **Example 1**. Line up the bracket and install the provided M6 fasteners (**Example 2**). Install the fasteners finger tight, as this will make it easier to install the light bar.



Example 1



Example 2

2. Mounting Light Bar.

The mounts are designed to hold a 30"-32" light bar using the mounting hardware that is included with most light bars. Attach the light bar to the mounts. If you are installing a 30" light bar, the mounts need adjusted all the way together with the slide adjustment on the bracket mounting fasteners. For larger light bars, slide the mounts away from each other. After the light bar is attached to both mounts, use the adjustment slots to center the light bar with the Jeep. When the light bar is in place, secure the mounts by tightening the M6 fasteners shown in **Example 2**. The finished product will look like the setup shown in both **Example 3** and **Example 4**.



Example 3



Example 4