



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS



2015-2016 CHEVROLET COLORADO / GMC CANYON

Z322671 / Z332671-KIT

REAR BUMPER LED LIGHT MOUNTS

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.

PARTS INCLUDED

- (1) Driver Side front bumper fog lamp cover LED Light Mount Bracket
- (1) Passenger Side front bumper fog lamp cover LED Light Mount Bracket

LED LIGHTS INCLUDED

- Z322671 - No LED Lights Included
- Z332671-KIT - (4) ZROADZ 3" LED Light Pods

HARDWARE INCLUDED

- (8) - M6 8mm x 25mm Button Head Allen Cap Screw - Stainless Steel
- (8) - M6 Hex Nut, Stainless Steel
- (8) - M6 Flat Washers
- (8) - 10-32 Nylon Lock Nuts
- (8) - #10 Flat Washers

TOOLS REQUIRED

- Torx Bit Set
- Various Socket Set
- Ratchet Tool
- Ratchet Extensions

INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS.
* IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

BEFORE YOU BEGIN

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.

LED LIGHT BRACKET INSTALLATION

- STEP 1** 1) Using a T15 Torx Bit, remove the torx screws the screws that secure the wheel well liner.



FIG 1

MOVE ONTO
STEP 2

STEP 2

- 2) Listen and remove all the screws.

SEE FIGURES 2 - 4



FIG 2



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 3

STEP 3

SEE FIGURE 3

3) Remove screws to pull gain back and gain access behind the wheel well liner.



FIG 4

STEP 4

SEE FIGURES 4 - 6

4) Underneath near the front bumper lower lip, you will find one more screw that holds the front of the bottom plastic basket plate. Remove and set aside for later.



FIG 5

STEP 5

SEE FIGURE 7

5) It is now time to remove the front bumper fog light covers.



FIG 6

STEP 6

SEE FIGURE 8 - 9

6) From the backside and underneath, access the back lower bumper and remove the factory plastic fog light cover.

Remove by prying out and freeing the plastic tabs from the fog light pod receptacle with a broad flat head screw driver.

REMOVE FOG LIGHT COVER



FIG 7



FIG 8

REAR BUMPER LED LIGHT MOUNTS - INSTALL COMPLETE



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 9

STEP 7

SEE FIGURE 9

7) The plastic fog light cover is now ready to be pulled free and removed from vehicle's front bumper.



FIG 10

STEP 8

SEE FIGURES 10

8) Go ahead and closely inspect the vehicles factory fog light opening to gain familiarity of how the ZROADZ mounting bracket will install.



FIG 11

STEP 9

SEE FIGURE 11 & 12

9) Begin installing the new ZROADZ's LED Fog Light Replacement by feeding the LED Light's wiring through the factory fog light receptacle.



FIG 12

STEP 10

SEE FIGURE 13 & 14

10) The new ZROADZ's LED Fog Light Replacement will be installed by inserting the hardware mounting studs into the vehicles factory bumper locating holes.

The ZROADZ's LED Fog Light Replacement will sit relatively flush inside the bumper factory fog light opening inset.

INSTALL ZROADZ MOUNTS



FIG 13



FIG 14

REAR BUMPER LED LIGHT MOUNTS - INSTALL COMPLETE



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.



FIG 15

STEP 11

SEE FIGURE 15

11) The ZROADZ's LED Fog Light Replacement will sit relatively flush inside the bumper factory fog light opening inset.



FIG 16

STEP 12

SEE FIGURES 16-18

12) Using a 10mm Nut Driver, or socket and the provided hardware, tighten down the ZROADZ LED Fog Light Replacement from the backside and underneath.



FIG 17

STEP 13

SEE FIGURE 17 & 18

13) Complete the install by tightening down the provided hardware onto the mounting studs.



FIG 18

STEP 14

SEE FIGURE 19 & 20

14) The new ZROADZ LED Fog Light Replacement is now installed. Check over your work and inspect for proper alignment with the vehicles lower front bumper, fog light pod openings, and ZROADZ Fog Light Replacement covers.

Once satisfied with the look give everything a once over and finally tighten it all to standard torx specifications.

INSTALL COMPLETE



FIG 19



FIG 20

REAR BUMPER LED LIGHT MOUNTS - INSTALL COMPLETE