

ZROADZ DYNAMIC LED MOUNTING SOLUTIONS



PROFESSIONAL INSTALL RECOMMENDED

2018 JEEP WRANGLER JL

PART#: Z374831-KITS / Z374831-KIT2S / Z374831-KIT4S

FRONT ROOF / A-PILLAR LED LIGHT MOUNTS

PARTS INCLUDED

- (1) Driver Side Mounting Bracket
- (1) Passenger Side. Mounting Bracket

LED LIGHTS INCLUDED

Z374831-KITS - (1) 50" Single Row LED Light Bar

Z374831-KIT2S - (1) 50" Single Row LED Light Bar & (2) 3" Pods

Z374831-KIT4S - (1) 50" Single Row LED Light Bar & (4) 3" Pods

INSTALLERS NOTE:

DO NOT INTALL ANY LIGHT BAR LARGER THAN 52" IN WIDTH.

HARDWARE INCLUDED

- (1) DriverSide Gasket Base Support
- (1) Passanger Side Gasket Base Support
- (8) Gasket Strips
- (4) ZROADZ Logo Backing Plate
- (4) 3/4" x 1/4" Aluminum Spacers
- (4) 3/8" x .810 Aluminum Spacers
- (4) 3/4" x 13/32" Aluminum Spacers
- (4) M6 x 1mm x 50mm Round Head Black Screws
- (4) M8 x 1.25mm x 30mm Button Head Black Screws
- (8) 10-32 x 1/2" Button Head Screws
- (8) #10-32 Flange Nuts
- (2) Torx Screws
- (2) 5/16" Black Flat Washers
- (1) 1" Long Torx T-40 Bit
- (1) Power Cable Wiring Harness

TOOLS REQUIRED

- Air Hose & Nozzle
- Alcohol Cleaning Solution
- Cleaning Rag
- Socket Set & Ratchet Tool Ratchet Extensions
- Various Wrenches
- Dikes or SnipsTorq Bit Set
- Heat Gun

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS. * IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

BEFORE YOU BEGIN

START HERE

LED LIGHT BRACKET INSTALLATION

INSTALLATION GUIDE

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.



1) Layout and organize all the provided parts.

SEE FIGURE 2

PRO TIP:

APPLY A PROTECTIVE LAYER OF 3M MASKING TAPE AROUND THE APPLICATION AREA.

STEP 2

2) Match up the gaskets to the appropriate mounting bracket.

Peel off the gasket protective tape.

FIG 2

PAGE 1


INSTALLERS NOTE:



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED



STEDS 2 & A

SEE FIGURE 3 & 4

Identify which Gasket goes on Driver Side and which Gasket goes on Passenger side. Each has a pattern that matches the Mounting Brackets.

- 3) Carefully put gasket into position sticky side down facing Mounting Brackets.
- 4) Take the Gasket strips and put them into place along the A-Pillar section as seen in Figure #4.







STEP 5

SEE FIGURES 5 & 6

5) Remove JEEP A-Pillar Screws from vehicle. There are (2) on top near Hood Hinge and (2) on side near door hinge as seen in Figures #5 & #6.







STEP 6

NSTALLERS NOTE: Mock Up LED Lights and plumb wires.

SEE FIGURES 7-9


6) With the Screws removed, you should now be able to remove the Vehicle's A-Pillar / Fender panel. Plumb any and all LED Lights power harness through and behind fender / hood. It is recommended and designed to hide the roof level LED Light Bar Power Wire behind the ZROADZ Mounting Brackets. Now is the time to carefully set LED Light Bar up on roof area and mock up the power wire along Vehicle's A-Pillar exterior.


LED LIGHT BRACKET INSTALLATION - CONTINUED




DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED








STEP 7

SEE FIGURES 10 - 12

7) Put back into place and install Vehicle's Fender Panel with new supplied hardware as follows: Assemble the provided Aluminum Spacers (3/4" x 13/32" - Figure #10) & (3/8" x .810" - Figure #11) as seen & configured in Figure #15 and put them into the Vehicle's TOP mounting locations. The Aluminum Spacers will be stacked on top of each other with the long one going in first.







SEE FIGURE 16 STEP 8

8) Take the other provided Aluminum Spacers (3/4" x 1/4" Aluminum Spacers) and insert them into the Vehicle's SIDE mounting locations.





STEP 9

9) Carefully pu into place the ZROADZ

Mounting Brackets to Jeep JL A-Pillar. Check for clearnaces and proper placement of gaskets for coverage and protection of vehicle finish. Route & hide the Roof Level LED Light Bar Power Harness down the Vehicle's A-Pillar behind ZROADZ Mounting Bracket. Use the provided M6 x 50mm Round Head Black Screws to secure mounts to Jeep.

LED LIGHT BRACKET INSTALLATION - CONTINUED



ZROADZ

DYNAMIC LED MOUNTING SOLUTIONS

LED LIGHT BRACKET INSTALLATION - CONTINUED

TO PARTS: Z374831 / Z374831-KIT

STEP 10

SEE FIGURES 18 & 19

10) Install any ZROADZ LED Light Pods to the pre-determined A-Pillar Tabs using the provided LED Light Pod Hardware.

M8 x 20mm Bolts M8 Lock Washers M8 Hex Nuts





LEVEL LED LIGHT BAR INSTALI

STEP 11

SEE FIGURES 20 - 22

11) Put into place the LED Light Bar and position it at Vehicle's Roof Level in between the ZROADZ Mounting Brackets.

Secure LED Light Bar using the provided T-40 Torx Anti-Theft Screws and the 5/16" Flat Washers



STEP 12

12) Go over and tighten all hardware. Secure all LED Light Power Wires and connect harness.

STEP 13

13) ZROADZ recommends LED Lights be wired with ZROADZ harness kit (part# Z390020S-A) or by utilizing a compatible custom wiring harness. Wiring must be installed by competent & knowledgable automotive electrician.

FIG 21

ADJUSTMENT TIPS STEP 14

14) To adjust the angle of your Light Bar, rotate the LED(s) to adjust the angles till your desired light pattern is reached. There will be minimal adjustment due to curved light bar orientation. You may than tighten the hardware and secure everything into place. Be careful not to over tighten the mounting hardware.

It is best to adjust the angle with the vehicle on level ground with lights facing a wall, garage door or other solid barrier. We recommend checking from a distance of 25'. Your installation is now completed.



LED LIGHT BRACKET INSTALLATION - PROCESS COMPLETE