





PARTS INCLUDED

- (1) Driver Light Mount Bracket
- (1) Passenger Light Mount Bracket



Kit w/ (2) 6" LED Light Bars

Mounting Brackets Only

* Simulated Rendering, Not actual parts.

LED LIGHTS INCLUDED

Z385731 - No LED Lights Included Z385731-KIT - (2) ZROADZ 6" LED Light Bars * LED Lights include a separate hardware kit.

HARDWARE INCLUDED

Z385731

- (1) Left Side Rear Hanging Bracket L
- (1) Right Side Rear Hanging Bracket R (1) - Universal Left Side Bracket LED Cradle
- (1) Universal Right Side Bracket LED Cradle
- (4) M8 x 16mm Button Head Allen Cap Stainless Steel Bolts
- (4) M8 Stainless Steel Hex Nuts
- (4) 5/16" Flat Washers Black
 - TOOLS REQUIRED
 - Various Socket Set
 - Various Wrenches
 - Ratchet Tool

PAGE 1

Ratchet Extensions

Z38573 1-KIT

- (1) Left Side Rear Hanging Bracket L
- (1) Right Side Rear Hanging Bracket R
- (1) Universal Left Side Bracket LED Cradle
- (1) Torx Bit T-40
- (4) M8 Tamper Proof Bolt

(1) - Universal Right Side Bracket LED Cradle

- (4) M8 x vv Button Head Allen Cap
 - Stainless Steel Bolts

2015-2016 FORD F-150

Z385731 / Z385731-KIT **REAR BUMPER LED LIGHT MOUNTS**

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT © 2016 - ZROADZ LED. INC.

INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS. * IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

BEFORE YOU BEGIN

LED LIGHT BRACKET INSTALLATION

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.



STEP 1 1) From under the rear bumper, take your ZROADZ LED light mount and mock it up into position. This will help you gain familiarity with the mounting orientation. Identify these two bolts that hang the rear bumper on either vehicle corner.

STEP 2

2) Using a Socket, or Wrench, loosen the two bolts about half way out.

Do not remove hardware. Only back out threads a few turns.







LED LIGHT BRACKET INSTALLATION - CONTINUED



3) Prop the LED bracket mounts into place by sliding

mounting tab slots up and around the factory bolts. Make sure the brackets are on the back side of bumper

mount and NOT in-between bumper and bumper

mount. Repeat on opposite side of vehicle.

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT © 2016 - ZROADZ LED, INC.



STEP 4

FIG 6

FIG 7

SEE FIGURES 5-8

4) Using your best judgement, move the adjustable bracket piece into your preferred position, and finally tighten everything up for now.

Look over your work and verify that the correct bracket has been mounted on the appropriate side of vehicle.



STEP 5

STEP 3

SEE FIGURE 5

SEE FIGURE 4

Wire LED Light with a ZROADZ optional wiring harness kit (part# Z390020S-A) or by utilizing a compatible custom wiring harness. ZROADZ recommends LED Lights be wired with ZROADZ harness kit (part# Z390020S-A).

STEP 6 ADJUSTMENT TIPS

6) To adjust the angle of your Light Bar, rotate the LED(s) to adjust the angles till your desired light pattern is reached. You may than tighten the hardware and also mounting bracket and secure everything into place. Be careful not to over tighten the mounting hardware.

It is best to adjust the angle with the vehicle on level ground with lights facing a wall, garage door or other solid barrier. We recommend checking from a distance of 25'. Your installation is now completed.

LED LIGHT BRACKET INSTALLATION - PROCESS COMPLETE

PAGE 2



FINAL INSTALLATION