





# 2016 NISSAN TITAN

### Z387581 / Z387581-KIT REAR BUMPER LED LIGHT MOUNTS

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT ©2016 - ZROADZ LED, INC.

# **INSTALLATION GUIDE**

### START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

#### \* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS. \* IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

### **BEFORE YOU BEGIN**

### LED LIGHT BRACKET INSTALLATION

START HERE: Turn off engine, chalk tires with stop block, open the hood and disconnect the battery.



**STEP 1** 1) From under the rear bumper, take your ZROADZ LED light mount and mock it up into position. This will help you gain familiarity with the mounting orientation. Identify these two bolts that hang the rear bumper on either vehicle corner.

### STEP 2

2) Using a Socket, or Wrench, loosen the two bolts about half way out.

Do not remove hardware. Only back out threads a few turns.



# PARTS INCLUDED

- (1) Driver Light Mount Bracket
- (1) Passenger Light Mount Bracket



Mounting Brackets Only

w/ (2) 6" LED Light Bars

Kit -

\* Simulated Rendering, Not actual parts.

### LED LIGHTS INCLUDED

**Z387581** - No LED Lights Included **Z387581-KIT** - (2) ZROADZ 6" LED Light Bars \* LED Lights include a separate hardware kit.

# HARDWARE INCLUDED

### Z387581

- (1) Left Side Rear Hanging Bracket L
- Right Side Rear Hanging Bracket R
  Universal Left Side Bracket LFD Cradle
- (1) Universal Right Side Bracket LED Cradle (1) Universal Right Side Bracket LED Cradle
- (4) M8 x 16mm Button Head Allen Cap
- Stainless Steel Bolts (4) - M8 Stainless Steel Hex Nuts
- (4) 1/16" Flat Washers Black
- Stainless Steel Bolts (4) - M8 Stainless Steel Hex Nuts (8) - 5/16" Flat Washers Black

(4) - M8 Tamper Proof Bolt

(4) - M8 x vv Button Head Allen Cap

Z387581-KIT

(1) - Torx Bit T-40

(1) - Left Side Rear Hanging Bracket - L (1) - Right Side Rear Hanging Bracket - R

(1) - Universal Left Side Bracket LED Cradle

## **TOOLS REQUIRED**

- Various Socket Set
- Various Wrenches
- Ratchet Tool
- Ratchet Extensions

PAGE 1





## LED LIGHT BRACKET INSTALLATION - CONTINUED



3) Prop the LED bracket mounts into place by sliding

mounting tab slots up and around the factory bolts. Make sure the brackets are on the back side of bumper

mount and NOT in-between bumper and bumper

mount. Repeat on opposite side of vehicle.

PARTS ARE PATENT PENDING. ALL RIGHTS RESERVED - COPYRIGHT © 2016 - ZROADZ LED, INC.



### STEP 4

### SEE FIGURES 5-8

4) Using your best judgement, move the adjustable bracket piece into your preferred position, and finally tighten everything up for now.

Look over your work and verify that the correct bracket has been mounted on the appropriate side of vehicle.

**FINAL INSTALLATION** 



### STEP 5

STEP 3

### **SEE FIGURE 5**

**SEE FIGURE 4** 

Wire LED Light with a ZROADZ optional wiring harness kit (part# Z390020S-A) or by utilizing a compatible custom wiring harness. ZROADZ recommends LED Lights be wired with ZROADZ harness kit (part# Z390020S-A).


### STEP 6 ADJUSTMENT TIPS

6) To adjust the angle of your Light Bar, rotate the LED(s) to adjust the angles till your desired light pattern is reached. You may than tighten the hardware and also mounting bracket and secure everything into place. Be careful not to over tighten the mounting hardware.

It is best to adjust the angle with the vehicle on level ground with lights facing a wall, garage door or other solid barrier. We recommend checking from a distance of 25'. Your installation is now completed.

# **LED LIGHT BRACKET INSTALLATION - PROCESS COMPLETE**

# PAGE 2



### FIG 8

### Learn more about off-road lights on our website.