



ZROADZ[®]

OFF ROAD PRODUCTS



2014-2022 TOYOTA TUNDRA

Z739661, Z739671

SIDE STEPS

PARTS INCLUDED

Z739661, Z739671

- (1) Driver Side Assembly
- (1) Passenger Side Assembly

HARDWARE INCLUDED

Z739661, Z739671

- (16) M8 bolts

INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS.
* IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR MODEL OR PART.

STEP 1



- 1) If installed, begin by removing any existing side steps.

STEP 2



- 2) Locate the (2) bolts for each of the (4) mounting points found on the underside of the truck. Using a 12 MM socket and power drill remove each side step.



ZROADZ®
OFF ROAD PRODUCTS

INSTALLATION - CONTINUED

STEP 3



3) Prepare the ZROADZ Side Step for install. Identify the Driver / Passenger Side Step by having the ZROADZ logo right side up as you mount it. Use the help of another person to mount the side step.

STEP 4



4) Using (8) M8 bolts for each side and the same mounting points as before secure the ZROADZ Side Step onto the underside of the truck.