



MODEL 536 - 35 TON AIR AXLE JACK

PART		KIT INCLUDES		
ORDER NUMBER	KIT DESCRIPTION	REF. #	DESCRIPTION	QTY
536-KHU	HYDRAULIC UNIT COMPLETE	50		1
536-5.12	HANDLE BOLT	5,12	HANDLE BOLT	1
	SPRING WASHER	5,13	SPRING WASHER	1
536-2.0	PISTON ROD ASSEMBLY	2.0	PISTON ROD ASSEMBLY	1
	PISTON ROD	2.1	PISTON ROD	1
	PACKING	2.2	PACKING	1
	SCREW	2.3	SCREW	1
	BUSHING	2.4	BUSHING	1
	SNAP RING	2.5	SNAP RING	1
	PACKING RETAINER	2.7	PACKING RETAINER	1
	SNAP RING	2.31	SNAP RING	1
	BACK UP RING	2.32	BACK UP RING	1
536-12.0	ADAPTER SET		ADAPTER SET	
	ADAPTER A	12.5	ADAPTER A	1
	ADAPTER B	12.3	ADAPTER B	1
	ADAPTER C	12.4	ADAPTER C	1
	HOLDER	12.5	HOLDER	1
	U-BOLT	12.6	U-BOLT	2
	NUT	12.7	NUT	4
	SPRING WASHER	12.8	SPRING WASHER	4
	HITCH PIN	12.9	HITCH PIN	3
536-1.3	WHEEL ASSEMBLY		WHEEL ASSEMBLY	
	WASHER	1.2	WASHER	1
	WHEEL	1.3	WHEEL	1
	SNAP RING	1.4	SNAP RING	1

536-10.30	AIR VALVE ASSEMBLY	10.3	AIR VALVE ASSEMBLY	
	VALVE BODY	10.1	VALVE BODY	1
	NUT	10.2	NUT	1
	O-RING	10.3	O-RING	1
	O-RING	10.4	O-RING	1
	PACKING	10.5	PACKING	1
	THROTTLE	10.6	THROTTLE	1
	SPRING	10.7	SPRING	1
	LEVER	10.8	LEVER	1
	LEVER PIN	10.9	LEVER PIN	1
	LOCK LEVER	10.10	LOCK LEVER	1
	FILTER	10.22	FILTER	1
536-5.11	HANDLE FORK	5.11	HANDLE FORK	1
	BOLT	5.12	BOLT	1
	SPRING WASHER	5.13	SPRING WASHER	1
	CONNECTING ROD	5.14	CONNECTING ROD	1
	CONNECTING ROD	5.15	CONNECTING ROD	1
	UNIVERSAL JOINT	5.16	UNIVERSAL JOINT	1
	SPRING PIN	5.17	SPRING PIN	1
	SPRING PIN	5.18	SPRING PIN	1
	COTTER PIN	5.20	COTTER PIN	1
	HANDLE FORK BRACKET	6.3	HANDLE FORK BRACKET	1
536-2.22	SUPPORT SPRING SET		SUPPORT SPRING SET	
	SPRING	2.21	SPRING	4
	SPRING HANGER	2.22	SPRING HANGER	1
	SCREW	2.23	SCREW	4
	NUT	2.24	NUT	4

536-8.2	AIR MOTOR ASSEMBLY		AIR MOTOR ASSEMBLY	
	PACKING WASHER	7.1	PACKING WASHER	1
	MUFFLER COVER	7.2	MUFFLER COVER	1
	O-RING	7.3	O-RING	1
	VALVE ROD	7.4	VALVE ROD	1
	RUBBER PAD	7.5	RUBBER PAD	1
	PACKING WASHER	7.6	PACKING WASHER	1
	COVER	7.7	COVER	1
	SPRING WASHER	7.8	SPRING WASHER	1
	HEX SOCKET SCREW	7.9	HEX SOCKET SCREW	4
	FILTER ELEMENT	7.10	FILTER ELEMENT	1
	FILTER	7.11	FILTER	1
	STEEL BALL	7.12	STEEL BALL	1
	STEEL BALL	7.13	STEEL BALL	2
	PLUNGER COVER	8.1	PLUNGER COVER	1
	AIR PUMP BODY	8.2	AIR PUMP BODY	1
	NYLON RETIANER	8.3	NYLON RETIANER	1
	O-RING	8.4	O-RING	1
	PACKING GUIDE	8.5	PACKING GUIDE	1
	NUT	8.6	NUT	1
	SPRING	8.7	SPRING	1
	WASHER	8.8	WASHER	1
	PLUNGER	8.9	PLUNGER	1
	RETAINER	8.10	RETAINER	1
	O-RING	8.11	O-RING	1
	O-RING	8.12	O-RING	2
	PISTON	8.13	PISTON	1
	STEEL BALL	8.14	STEEL BALL	2
536-5.0	HANDLE ASSEMBLY	5.0	HANDLE ASSEMBLY	
	UPPER HANDLE	5.1.1	UPPER HANDLE	1
	LOWER HANDLE	5.1.2	LOWER HANDLE	1
	KNOB	5.2	KNOB	1
	CONNECTING ROD	5.3.1	CONNECTING ROD	1
	CONNECTING ROD	5.3.2	CONNECTING ROD	1
	SPRING PIN	5.4	SPRING PIN	1
	STOPPER	5.5.1	STOPPER	1
	STOPPER	5.5.2	STOPPER	1
	LOCK LEVER	5.6	LOCK LEVER	1
	SPRING PIN	5.7	SPRING PIN	1
	SPRING	5.8	SPRING	1
	WASHER	5.9	WASHER	1
	BOLT	5.23	BOLT	1
	SPRING PIN	5.19	SPRING PIN	1
	BOLT	5.21	BOLT	2
	SPRING WASHER	5.22	SPRING WASHER	1

Parts Diagram



