

Quick Turn Spring Fixture

Accurately drill panels when installing quick turn fastener springs. Start with a 1/4" center hole and use the fixture to locate and drill 1/8" holes for mounting the springs. Size listed is spring center to center distance.

Part No. Description

- ALL19406.....Fixture For 3/4" Spring
- ALL19407.....Fixture For 1" Spring
- ALL19408.....Fixture For 1-3/8" Spring







REV100115